
HUMAN ROBOTICS


- muscle mechanics and control
- single-joint neuromechanics
- multi-joint multi-muscle kinematics
- multi-joint dynamics and control
- motor learning and memory
- interaction control
- motion planning and online control
- integration and control of sensory feedback
- applications in neurorehabilitation



- typical onejoint systems are the knee or the elbow, which can move in only one direction
- it is sometimes useful to analyze functions of more complex joints as a onejoint system
- example: wrist flexion/extension


ONE-JOINT SYSTEM

- joint with muscles fixed to the two body segments
- the torque applied at a joint depends on the moment arm
- the moment arm often varies with joint angle




ONE-JOINT SYSTEM

since individual
 muscles can only pull,
 there must be
 separate sets of
 muscles at opposite
 sides of a joint to
 actuate it




- agonist: prime movers, accelerating the limb
- antagonist: muscles counteracting the agonists and braking movement

SINGLE JOINT MOTION (1)



SINGLE JOINT MOTION (2)

- point-to-point
 (elbow)movements
 require activation of
 agonist (biceps) muscle
 for acceleration followed
 by activation of
 antagonist muscle
 (triceps) to decelerate
 and stop motion
- agonist activation increases with torque, i.e. with faster movement and larger load



[Lestienne, Experimental Brain Research 1979]

ELASTICITY OF AN ANTAGONIST MUSCLE PAIR

- stiffness $K \equiv \frac{dF}{dx}$

$$F = F_1 + F_2$$
 $x = x_1 = x_2$

$$\to K = \frac{dF}{dx} = \frac{dF_1}{dx} + \frac{dF_2}{dx} = \frac{dF_1}{dx_1} + \frac{dF_2}{dx_2} = K_1 + K_2$$

example: agonist-antagonist muscle pair

JOINT MECHANICS MODELLING

joint mechanics are frequently assumed to be a simple linear transformation of muscle mechanics:

$$\tau = \rho m$$
, $d\lambda = \rho dq$


m: muscle tension ρ : moment arm

 λ : muscle length q: joint angle

$$\to K_q \equiv \frac{d\tau}{dq} = \rho \frac{dm}{dq} = \rho^2 \frac{dR}{d\lambda} \equiv \rho^2 K_m$$


$$\rightarrow D_q \equiv \frac{d\tau}{d\dot{q}} = \rho \frac{dm}{d\dot{q}} = \rho^2 \frac{dP}{d\dot{\lambda}} \equiv \rho^2 D_m$$

JOINT MECHANICS MODELLING



- for simplicity we consider an antagonist pair with one flexor and one extensor
- in each muscle, stiffness increases with muscle tension, e.g. $K = \kappa_o + \kappa_1 m$

JOINT MECHANICS MODELLING



- stiffness $K_q \stackrel{\text{and}}{=} \rho_e^2 K_e + \rho_f^2 K_f$ increases with muscle tensions m_e and m_f , while torque depends on their difference: $\tau = \rho_e \, m_e \rho_f \, m_f$
- joint stiffness can be modulated independently of torque by co-contraction of antagonistic muscles

REFLEX


- reflex: involuntary and relatively stereotyped response to a specific sensory stimulus
- spinal reflex: sensory signals originating from receptors in muscles, joints, and skin, activate the neural circuitry entirely within the spinal cord responsible for muscle activation
- the same spinal circuits involved in reflexes may be used by higher brain centres to generate complex behaviour: decentralised control

MONOSYNAPTIC STRETCH REFLEX

 fastest and generally most powerful feedback loop (tendon-tap reflex)

 primary muscle spindle afferents (la) produce strong monosynaptic excitation of α-motoneurons of the same muscle

 excitation is also distributed to motoneurons of muscles which are close synergists at the same joint, as well as synergistic motoneurons at




Motor

MONOSYNAPTIC STRETCH REFLEX

• activity of la afferents also causes reciprocal inhibition of α -motoneurons of antagonist muscles


 inhibition is mediated by la inhibitory interneurons which receive convergent input from many sources, including both peripheral afferents, other interneurons and descending

pathways




Motor

STRETCH REFLEX DIAGRAM



STRETCH REFLEX EMG




earliest component of stretch reflex (monosynaptic reflex) is brief increase in electrical activity of muscle, typically after 20-30*ms* for arm

- duration of the electrical activity is generally less than 50ms, but force will last at least 200ms
- size of response depends mainly on velocity of stretch and state of motoneuron excitability

[Lee and Tatton Experimental Brain Research 1982]

STRETCH REFLEX EMG

- effect of increasing duration and amplitude of displacement on EMG responses from the wrist flexor
- responses at longer
 delays of up to 150ms
 can extend reflex force
 production to several
 hundred milliseconds





 size of longer latency responses depend on the amplitude and duration of the stretch, as well as mechanical factors such as stability and environmental dynamics or psychological factors such as intention (resist, ignore, etc.)

[Lee and Tatton Experimental Brain Research 1982]

SINGLE JOINT POSTURE

- subjects produce constant torque
- total torque due to displacement
- intrinsic: movement due to electrical stimulation if relaxed
- reflex= total intrinsic
- torque due to stretch reflexes occurs at some delay after perturbation





[Leger & Milner 2000, Clinical Biomechanics]

REFLEX MUSCLE ACTIVATION

- reflex pathways will be activated during voluntary movement due to output of muscle sensory receptors sensitive to movement variables
- central nervous system controllers must compensate for changes in motoneuron activation due to input from reflex pathways during movement


REFLEX MUSCLE ACTIVATION

- reflex feedback to muscles on both sides of a joint contributes to "apparent" stiffness and damping by means of a delayed change in muscle torque
- reflex impedance can be negative depending on the natural frequency, which increases with muscle activation
- currently there is no consensus on the most appropriate model structure for reflex feedback, which poses a problem for theoretical analysis of system stability
- this problem is partly resolved if torque due to muscle impedance can be assumed to be sufficiently greater than torque due to reflex feedback

JOINT ELASTICITY (1)

- elbow point-to-point movement
- (+-5*Nm*, 50*ms*) torque pulse at peak velocity
- loads: interface inertia, and added damping
- faster motion is stiffer
- load or larger speed produces a larger restoring force

(inear Control.



[Milner Experimental Brain Research 1993]


LINEAR CONTROL OF ROBOTS

- for tasks such as welding or milling, robots have to follow a trajectory
- linear PD control is typically used: motor torque to minimize the tracking error along movement

$$au(t) = P e(t) + D \dot{e}(t)$$
 $e(t) = q_p(t) - q(t)$ tracking error between the planned and realised trajectories

 $P=P^T$, $D=D^T$ positive definite matrices, e.g. diagonal matrices with positive gains

LINEAR CONTROL OF ROBOTS



$$\tau(t) = P e(t) + D \dot{e}(t)$$
$$e(t) = q_p(t) - q(t)$$

- PD controller to provide the motion dynamics...
- and stabilise the plant against perturbations

LINEAR ONE JOINT MODEL

$$\tau = I\ddot{q} + D\dot{e} + Ke$$

 q_p : undisturbed trajectory


 $e \equiv q_p - q$: kinematic error


D: damping, K: stiffness

I: inertia, \ddot{q} : joint acceleration

JOINT ELASTICITY (2)


- 1.0rad elbow reaching
- 0.15rad angle displacement during movement
- joint stiffness: $\frac{\overline{\triangle \tau}}{\overline{\triangle q}}$





JOINT ELASTICITY (3)


- 1.0rad elbow reaching
- 0.15rad angle displacement during movement
- joint stiffness: $\frac{\overline{\triangle \tau}}{\overline{\triangle a}}$
- stiffness increases linearly with torque.



JOINT ELASTICITY ADAPTATION

Do use have control of I, D& K independently? Yes!!

- wrist 30° reaching mvt
- unstable viscous load assisting motion
- subjects learned to reduce the oscillations
- second order linear model -> increase of damping and stiffness



[Milner and Cloutier Exp Brain Res 1993]